13.5. LABS



Exercise 13.4: Create a private share for a single user

• Create and share the directory /home/export/private/ as the share name private and populate it with files:

```
# mkdir /home/export/private/
# touch /home/export/private/PRIVATE_FILES_ONLY
# chown -R student: /home/export/private
```

- Create a **Samba** password for the student account.
- Allow full access to the student account.

Solution 13.4

1. Edit the file /etc/samba/smb.conf and add this stanza to the bottom.

```
[private]
   path = /home/export/private
   comment = student's private share
   read only = No
   public = No
   valid users = student
```

2. Add a samba password for student.

```
# smbpasswd -a student
```

LFS211: V_2017-12-01

3. From a remote system, verify the access for the student account:

```
$ smbclient -U student //SERVER/private
```

Test read and write access.

4. Create a **credential's** file with the student id and password for later use when adding the mounts to the fstab.

```
# echo "username=student" > /root/smbfile
# echo "password=student" >> /root/smbfile
# chmod 600 /root/smbfile
```

